



IMPORTANT WARRANTY & INSTALLATION
INSTRUCTIONS ATTACHED

*Please Forward All Attached Information to Consumer
Warranty Not Valid Unless Returned to CORSA Performance*

We ask that you take a few moments to complete our warranty registration form:

TO ACTIVATE YOUR WARRANTY GO TO:
CORSAPERFORMANCE.COM/WARRANTY



**For Full-Color Installation Instructions, Please Visit:
CORSAPERFORMANCE.COM and Search by Part Number**

Please be sure to review the enclosed instructions prior to beginning the installation process.
If you have any questions about the enclosed parts, instructions or encounter a problem during installation:
CALL CORSA PERFORMANCE TECHNICAL ASSISTANCE AT 800.486.0999

Please take time to read and understand these installation instructions.

CORSA recommends that the installation of this system be performed by a qualified service center or professional installer who has the necessary equipment, tools and experienced personnel. However, if you decide to perform this install the use of an additional person may be required.

CAUTION: Never work on a hot engine bay. Allow time for the vehicle to cool.

Recommended Tools:

- Flathead Screwdriver
- Assorted Socket-Set
- Ratchet
- Ratchet Extension

Please confirm that all parts are present according to the bill of materials before beginning the installation.

If something is missing call Tech Support at 440.891.099 or Toll Free: 1.800.486.0999

Hardware Kit				
1	4" Hump Hose	1	#5120 Filter w/ Clamp	1 MAF Sensor Gasket
2	#56 Clamps	1	2.5" x 3.5" Sleeve	
2	4mm x 12 Screws	2	#64 Clamps	

Preassembled Materials					
1	CORSA Filter Box	1	CORSA Air Duct	1	CORSA Air Box Lid
1	Filter Adapter	2	3/8 Snap Fitting	1	Lid Gasket
3	1/4 x 20 Lock Washers	1	1/2 Rubber Grommets	6	1/4 x 20 Truss Head Screws
3	1/4 Flat Washers	1	5/8 Snap Fitting	6	1/4 Rubber Washers
3	6mm x 16 Bolts				



*Locate your vehicle's battery and disconnect the negative battery cable.
This may reset the computer and clear old air flow data to help prevent CEL errors.*

Installation Instructions

REMOVAL



1. Remove the engine cover by lifting up and out.

Save for reinstallation



2. Disconnect the MAF sensor harness from the MAF sensor.



3. Disconnect the idle hose from the factory air duct.



4. Disconnect the EVAP hose from the factory air duct.

Continued on Next Page . . .

Installation Instructions

REMOVAL




5. Disconnect the crankcase vent hose from the factory air duct.



6. Disconnect the sound tube from the factory air duct.



7. Loosen the clamp holding the factory air duct to the throttle body.



8. Loosen the clamp holding the factory air duct to the air box.

Continued on Next Page . . .

Installation Instructions

REMOVAL



9. Remove the factory air duct from the engine compartment.



10. Remove the 10mm bolt holding the factory air box in place.

Save for reinstallation



11. Remove the tree rivet holding the MAF sensor harness to the factory air box.



12. Remove the factory air box from the engine compartment then remove the tree rivet holding the MAF sensor harness onto the wheel well.

Continued on Next Page . . .

Installation Instructions

CORSA INSTALL



13. Slide the CORSA air box over the factory air inlet.
Pro Tip: The use of a flathead screwdriver may aid in sliding the CORSA intake over the stock inlet.



14. Tighten the air box in place using the factory 10mm bolt.



15. Attach the 4in hump hose onto the filter adapter with a #64 clamp using a 5/16 socket or nut driver only.



16. Remove the factory MAF sensor from the stock air box.

Save for reinstallation

Continued on Next Page . . .

Installation Instructions

CORSA INSTALL



17. Remove the O-ring from the MAF sensor.



18. Attach the 3.5 x 2.5 sleeve onto the throttle body with a #56 clamp using a 5/16 socket or nut driver only.



19. Press the CORSA air duct into the 4in hump hose, do not tighten the clamp at this time.



20. Press the CORSA air duct into the 3.5in sleeve.

Continued on Next Page . . .

Installation Instructions

CORSA INSTALL



21. Adjust the angle of the CORSA air duct and tighten into place with a #56 clamp using a 5/16 socket or nut driver only.



22. Tighten the CORSA air duct onto the hump hose with a #64 clamp using a 5/16 socket or nut driver only.



23. Attach the idle bypass hose onto the 3/8 snap fitting on the CORSA air duct



24. Attach the EVAP, crankcase vent line and sound tube onto the CORSA air duct.

Continued on Next Page . . .

Installation Instructions

CORSA INSTALL



25. Attach the factory MAF sensor onto the CORSA air duct with the provided MAF gasket and 4mm screws.



26. Attach the MAF sensor harness onto the MAF sensor.



27. Reinstall the factory engine cover.



28. Attach the #5120 filter onto the filter adapter and tighten into place using a 5/16 socket or nut driver only.



29. Install the CORSA air box lid using the provided truss head screws and rubber washers.

30. **Reconnect the battery cable.**

*Check that this air intake complies with your Federal, State and Local laws.
We recommend saving your stock system.*

BEFORE ROAD TESTING

1. Start engine, leaving the transmission in park and securing the parking brake.
2. Make sure to look and listen for any unusual noises or air leaks. Repair problems if needed.
3. Once completed it will be necessary to check periodically, after a few heat cycles, for realignment and tightening of all connections.

CARE AND CLEANING

Check the Pro-5 cotton reusable filter periodically and remove any excessive dirt build-up by tapping the filter on the ground and brushing off the loosened dirt. Clean the filter by using a two stage cleaning kit to thoroughly clean and re-oil the filter. Re-oil every 10,000 miles without cleaning to improve filtering in sand and dirt. Clean only when dirt is very excessive or 50,000 miles.

FOR REPLACEMENT FILTERS REFERENCE FILTER #5120 & CALL 440-891-0999 OR TOLL FREE 1-800-486-0999