



CSF Veloster N / i30N DCT Intercooler (CSF #8238 / #8238B)

Installation Instructions

1. When installing the intercooler on a DCT equipped Veloster N / i30N you must replace the Left Side Charge Pipe to Intercooler Coupler with the included CSF x HPS 90° Coupler. Reuse the factory clamps to secure the new coupler
 - a. If your hands are small enough and you have the correct tools this can be accessed from below the vehicle. Otherwise remove the intake pipe in the engine bay and access from above.

