



## INSTALLATION GUIDE: AWE RS 5 COUPE TRACK OR TOURING EXHAUST

THIS PRODUCT IS INTENDED FOR THE FOLLOWING VEHICLES\*:

YEAR	MAKE	MODEL	SUBMODEL	ENGINE
2018-19	Audi	RS 5	Coupe	2.9T

THIS GUIDE IS INTENDED FOR THE FOLLOWING PART NUMBERS:

- 3020-33058 AWE Track Edition Exhaust for Audi B9 RS 5 Coupe - Non-Resonated
- 3015-33110 AWE Track Edition Exhaust for Audi B9 RS 5 Coupe - Resonated for Performance Catalysts
- 3015-33108 AWE Touring Edition Exhaust for Audi B9 RS 5 Coupe - Non-Resonated
- 3015-33112 AWE Touring Edition Exhaust for Audi B9 RS 5 Coupe - Resonated for Performance Catalysts
- 3820-31006 AWE Track Edition Conversion Kit for Audi B9 RS 5
- 3815-31008 AWE Touring Edition Conversion Kit for Audi B9 RS 5

Welcome to the AWE family, and congratulations on your purchase of the **AWE Track Edition or Touring Edition Exhaust** system for the B9 RS 5 Coupe.

Exquisite build quality and craftsmanship, coupled with industry leading performance, distinguish this exhaust system from all others.

\*For up to the minute fitment information, be sure to visit the AWE website. As always, AWE Performance Specialists are standing by for any questions, [right here](#).

# PARTS LIST



**INSPECT ALL PARTS PRIOR TO DISASSEMBLY OF VEHICLE; IF DAMAGED OR MISSING, PLEASE CONTACT THE PLACE OF PURCHASE IMMEDIATELY.**

## General Hardware

<b>QTY</b>	<b>Description</b>	<b>Part Number</b>
2	B9 2.9T downpipe gasket	8W0253115K
2	SBS valve simulator	150004
2	Valve motor pins	98380A457
8	3.00" Accu-Seal clamps	TAS300
1	B9 Center Brace	120019

## Integrated Clamp Hardware Kit (3910-41010)

<b>QTY</b>	<b>Description</b>	<b>Part Number</b>
4	1/4-20x 3/4" Bolt	1010-1003-4
4	1/4-20" locknut	90949A016

## B9 2.9T Hardware Kit (3910-41020)


<b>QTY</b>	<b>Description</b>	<b>Part Number</b>
6	M8x30 screws	91287A154
6	M8 locknut	94920A500

# PARTS LIST



**INSPECT ALL PARTS PRIOR TO DISASSEMBLY OF VEHICLE; IF DAMAGED OR MISSING, PLEASE CONTACT THE PLACE OF PURCHASE IMMEDIATELY.**

QTY	Description	Part Number
1	Driver side downpipe upper section	B49
1	Passenger side downpipe upper section	B50
1	Driver side non-res downpipe lower section	B79
1	Passenger side non-res downpipe lower section	B80
1	X Pipe section	B51
1	Driver side axle tube	B52
1	Passenger side axle tube	B53
1	AWE driver side RS oval tip diamond black	61000204-BLK
1	AWE passenger side RS oval tip diamond black	61000205-BLK
<b>Track Edition Only</b>		
1	Driver side track rear section	B54
1	Passenger side track rear section	B55
<b>Touring Edition Only</b>		
1	Driver side touring Rear Section	B75
1	Passenger side touring Rear Section	B76
<b>Optional resonators for performance downpipes</b>		
1	Driver resonated downpipe lower section	B81
1	Passenger resonated downpipe lower section	B82



## STEP 1



Installation of the AWE exhaust system is the reverse of the removal OEM exhaust.



Always refer to the manufacturer service manual for precise torque specifications on all OEM fasteners.



Under the hood, remove the plastic engine cover and turbo heat shield, to expose the turbos and catalyts.



**CAUTION:** The catalyts may be **VERY HOT** — allow adequate time for these to cool down before disassembly. Severe burns and injury will occur if skin comes into contact with a hot exhaust and/or catalyts.

Before exhaust removal, soak the fasteners that hold the exhaust in place with a penetrating oil.

Start by removing the 12mm nut on the driver side flange, shown by the arrow in **Figure 1-1 & 1-2**. This is the only nut that can be accessed from the engine bay.




## STEP 2

The remainder of the removal process takes place under the car. Removing the belly pan is accomplished by removing the fasteners as shown by the arrows in **Figure 2**.

One (1) T25 Torx, at **Arrow A**.

Two (2) quick release fasteners, at **Arrows B**.

Five (5) quarter-turn fasteners, at **Arrows C**.




## STEP 3



**NOTE:** Before removing any braces or hanger supports, be sure the exhaust is supported either by a second set of hands or pole jacks.

Remove the four (4) 10mm triple square bolts that secure the cross brace in place, as shown by the arrows in **Figure 3**.

The mid-muffler hanger bracket is also held into place through these bolts; once removed, set the hanger and bracket aside for reuse on the AWE X-pipe section (part B51).



## STEP 4



Unplug the valve control harness from the valve motors, located by **Arrows A** in **Figure 4-1**.

With pole jacks in place, supporting the rear sections of the OEM exhaust, remove the hanger bracket bolts located by the **Arrows B** in **Figure 4-1**.

Passenger side bolt location shown by the arrow in **Figure 4-2**.




**PRO-TIP:** Spray a little penetrant oil at the part of the hanger post that goes through the green hanger bushing. This will make removal and assembly go a bit smoother.



## STEP 5

With the OEM rear mufflers still supported, loosen the four (4) 13mm bolts that secure the sleeve clamps into place, as shown by the arrows in **Figure 5**.




## STEP 6

The hanger bushing, shown by the arrow in **Figure 6-1**, is the last part that holds the OEM rear exhaust section in place. Remove the hanger bar from the bushing, leaving the hanger assembly mounted to the vehicle.

Slide the sleeve clamps, loosened in *Step 5*, forward towards the front of the car and remove the rear section from the vehicle.


Remove the rear hanger assembly from the exhaust, location shown by the arrows in **Figure 6-2**. Reinstall the hanger assemblies into the original locations on the car.



## STEP 7

Loosen and remove the two (2) last remaining 12mm nuts from the driver side exhaust flange at the catalytic converter, as shown by **Arrow A** in **Figure 7**.


Loosen and remove the 13mm bolt that secures the driver side downpipe to the support bracket, as shown by **Arrow B** in **Figure 7**.



## STEP 8

Next, we'll remove the passenger side downpipe which is slightly more difficult.



First, unbolt the heat shield shown by the arrow in **Figure 8**. No need to remove this from the vehicle, but it will give you a line of sight to the bolts that will need to be loosened and removed in the next step.



## STEP 9

Locate the bracket and hardware shown by the arrows in **Figure 9-1**, and remove as shown in **Figure 9-2**.

The bracket by the arrow in **Figure 9-2** needs to be twisted up and away to gain access to the flange bolts.




## STEP 10

Remove the three (3) 12mm nuts from the passenger side exhaust flange at the catalytic converter, as shown by the arrow in **Figure 10**.



**PRO-TIP:** Once you've gotten the nuts loose, it is possible to access a few of the nuts from the top side of the engine bay.



Again, this is the tough part—we used an extension with a universal attached to the socket and still had limited access and visibility.



## STEP 11

**Figure 11-1** shows the driver side removed and the downpipe support bracket twisted out of the way for the next installation step.

The arrow in **Figure 11-2** shows one nut location that can be hard to reach.



## STEP 12


### **AWE Performance Exhaust Installation:**

Install the downpipe upper sections (*part B49 & B50*) using the included flange gaskets and mounting hardware to secure them to the outlet flange of the factory catalyts.

Reinstall the mounting bracket and hanger hardware for both driver and passenger sides

Torque the exhaust flange nuts to manufacturer specification along with the spring-bolt into the support bracket. Be careful not to overtighten the spring-bolt.

The installation of either side is the reverse of the removal of the stock exhaust.



## STEP 13

It is crucial to install each section and Accu-Seal clamp correctly to prevent loose joints, exhaust leaks between the tubing connections and rattles.

**Arrow A** in **Figure 13** shows the expanded pipe and the preinstalled Accu-Seal clamp being brought up to the corresponding pipe.


**Arrow B** in **Figure 13** shows the overlapping pipe installed correctly over the corresponding pipe.

**Arrow C** in **Figure 13** shows the Accu-Seal clamp being brought to the edge of the expanded pipe.

### **NOTES:**



- **Do not** torque any Accu-Seal clamp until the entire exhaust has been installed and adjusted.
- Torque specification is a minimum of 60 ft/lbs



## STEP 14


Install the downpipe lower sections next using two (2) of the included 3.0" Accu-Seal clamps.

For the OE catalyts installation, you are installing a straight tube section (*part B79 & B80*)

For the AWE performance catalyts, it is highly advised to install the optional resonated sections (*part B81 & B82*)

Driver side resonated section (*B81*) shown by **Arrow A** in **Figure 14**.

Passenger side resonated section (*B82*) shown by **Arrow B** in **Figure 14**.



## STEP 15


Transfer the OEM hanger bracket and bushing onto the correlating hanger post on the AWE X-Pipe Section, shown by **Arrow A** in **Figure 15**.

Place two (2) 3.0" Accu-Seal clamps over the inlets of the X-pipe section (*part B51*) and install into place, as shown by **Arrows B** in **Figure 15**.

Insert the AWE hanger post into the bushing that was reinstalled onto the vehicle in step 6. This is shown by **Arrow C** in **Figure 15**.




**PRO-TIP:** Installing both hangers before installing the cross-brace will make installation easier.



## STEP 16

Place a 3.0" Accu-Seal clamp over the inlet of the passenger axle tube (*part B53*) and install onto the X-pipe section, as shown by **Arrow A** in **Figure 16**. This pipe must be installed first due to the geometry of these sections.

Place a 3.0" Accu-Seal clamp over the inlet of the driver axle tube (*part B52*) and install onto the mid-muffler section, as shown by **Arrow B** in **Figure 16**.




## STEP 17

Place a 3.0" Accu-Seal clamp over the inlet of the driver side rear section (**Track Edition: part B54**) or (**Touring Edition: part B75**) and install onto the outlet end of the driver axle tube, as shown by **Arrow A** in **Figure 17**.

Place a 3.0" Accu-Seal clamp over the inlet of the passenger side rear section (**Track Edition: part B55**) or (**Touring Edition: part B76**) and install connect it to the passenger axle tube, as shown by **Arrow B** in **Figure 17**.

Insert each hanger bar into the hanger bushing, as shown by **Arrows C** in **Figure 17**.



## STEP 18

Installing the AWE RS Oval Tips is next; these parts have an integrated clamp that includes their own hardware. Torque specification for these is 15 ft./lbs.

Preassemble the hardware onto the integrated clamp, making sure the nut is facing the ground upon installation as shown by the arrow in **Figure 18**. Using a little anti seize on the threads will make tightening the tips much easier.

Loosely orient the tips as desired, and **snug** the nut and bolt to clamp the tip in-place.



**NOTE:** DO NOT torque the tips just yet, this will happen after the next step.




FIGURE 18

## STEP 19

Install the included AWE Chassis Brace re-using the factory hardware.

Orientation is important here, as the bolt pattern for the bracket is unique and can only be assembled as shown by the arrow in **Figure 19**.



FIGURE 19

## STEP 20

With everything installed onto the car, you are ready to adjust the exhaust and begin the final torque procedure. Minimum torque specification for the Accu-Seal clamp is 40 ft.lbs.



**PRO-TIP:** The tubing moves a tiny bit as you tighten each section in progression, so keep an eye on everything and readjust as you go, if needed.

Below, **Figure 20** shows the start to finish sequence for torquing the Accu-Seal clamps.

Adjustment is critical at this point because the AWE exhaust utilizes more space than the original tube path that the manufacturer provided.

With the AWE chassis brace installed, starting up front with the downpipes and X-pipe sections, adjust everything so there is adequate space between the factory heat shielding.

Once this part is satisfied, begin torquing the Accu-Seal clamps to the minimum torque specification stated above.

Finally, with all the Accu-Seal clamps torqued to specification, torque the integrated clamps on the RS Oval tips to a minimum of 15 ft./lbs.

The next and final step is the installation of the AWE valve simulator brackets, located on the next page.




FIGURE 13

## STEP 21

### Valve Simulator Bracket Installation:

Remove each factory valve motor from the factory mounting location on the OE exhaust system.



**NOTE:** The pin shown in **Figure 21-1** is critical to the function of the valve simulator bracket. Make sure this is installed correctly.

Using the factory hardware, install the driver side valve motor onto one of the included valve motor brackets and pins, as shown in **Figure 21-1**.

Use a few cable-ties to secure the assembly up and away from the exhaust, as shown by **Arrow A** in **Figure 21-2**.


Reconnect the factory harnesses to the valve control motors, as shown by **Arrow B** in **Figure 21-2**.

Repeat the valve simulator bracket installation for the passenger side.



**PRO-TIP:** A properly indexed OE valve motors is critical to a smooth installation. If the valve motors have been operating while disconnected from the factory valve body, re-indexing will be required.

**Installation is complete!**



## ENJOY!



## TROUBLESHOOTING

Issue	Solution
Exhaust is not fitting correctly	Most fitment issues are due to improperly adjusted exhaust. This includes tip fitments and rattling due to chassis contact. Check out our <a href="#">fitment guide</a> for more installation tips.
Wrong or missing parts	Double check the parts list for your system and compare them with what you received. Fill out our contact form, found below and let us know what parts you need.

## CARE

Once installed properly, your AWE exhaust will provide years of trouble-free performance.

The exhaust volume and sound will settle with usage; 800-1000 miles is required to break-in new exhaust systems.

Also, please note that the rear **180Technology®** resonator has a small drain hole to allow condensation to escape. Water drops from this area are normal.

Periodic cleaning of exhaust tips is necessary to maintain proper finish, especially in areas prone to road salt and caustic deicing solutions. Use a mild soap and water solution or car wax to clean the finish. Avoid using abrasive polishes, as they can scratch the finish.

Any questions or comments,  
please do not hesitate to contact us:

**AWE**  
199 Precision Drive  
Horsham, PA 19044  
215-658-1670  
[CONTACT FORM](#)

## WARRANTY

Up-to-date warranty information is found [HERE](#).